BEST IN GAMES, SAUNAS,
POOL AND PATIO

7’ AVALON OUTDOOR POOL TABLE – DRIFTWOOD
RB1070



FREETIME FUN
1830 E. FABYAN PKWY.
BATAVIA, IL 60510
WWW.FREETIMEFUN.COM

Check all packaging before discarding.

Be sure all parts identified in the assembly manual are included.

Don't assemble if parts are missing.

If you are missing parts or have questions please contact our toll free line at 1-888-620-6088.

Thank you for purchasing this product. If you experience any issues during assembly or use of this product, please don't hesitate to contact Customer Service at **1-888-620-6088** for immediate assistance.

ASSEMBLY TIPS






IMPORTANT! PLEASE READ THESE ASSEMBLY INSTRUCTIONS IN ENTIRETY BEFORE ASSEMBLING YOUR PRODUCT.

Estimated Assembly Time: 60 minutes.

1. Find a clean, level surface to begin the assembly of your game table. Assembly will require two adults. You may want to carefully cut the four corners of the box so that the bottom of the box can be used as your work surface.
2. Remove all of the contents from the box and verify that you have all of the parts shown on the Parts List before you begin assembly. **Note: Some parts are pre-installed or pre-assembled.**
3. **When installing parts that have more than one screw or bolt, hand tighten all screws or bolts in place before final tightening with screwdriver or wrench.**
4. Electric screwdrivers may be helpful during assembly; however, please set a low torque and use extreme caution because screws may be stripped if overtightened, resulting in damaged parts.
5. **CAUTION: THE TABLE IS VERY HEAVY; WE SUGGEST THAT FOUR STRONG ADULTS ASSIST IN THE ASSEMBLY PROCESS AND POSITIONING OF THE TABLE INTO ITS FINAL DESTINATION.**


► **THIS PRODUCT IS INTENDED FOR INDOOR USE ONLY.**
DO NOT DRAG THE TABLE WHEN MOVING IT AS THIS MAY CAUSE DAMAGE TO THE LEGS.

TABLE PARTS

#1  Leg Bolt M8x18mm XRB20000(16)	#2  Washer M8x22mm XRB20000(16)	#3  Leg XRB20001(4)	#4  Table Cabinet Frame XRB20002(1)	#5  Leg Leveler Pre-installed XRB20003(4)
#6  Table Cover XRB20004(1)	#7  2 Piece - 57" Composite Cue XRB20005(2)	#8  2.25" Billiard Ball Set XRB20006(1)	#9  Table Brush XRB20007(1)	#10  Chalk XRB20008(2)
#11  Triangle XRB20009(1)	#12  Allen Wrench XRB20010(1)	#13  Side Pocket - Pre-installed XRB20011(2)	#14  Corner Pocket - Pre-installed XRB20012(4)	


7’ AVALON OUTDOOR POOL TABLE

STEP 1



Align the table legs (#3) with the pre-threaded holes on the cabinet frame. Insert a bolt (#1) and washer (#2) through each hole, then thread them into the frame. Tighten all bolts firmly to secure.


STEP 2






Carefully turn the table upright and place it in your desired location. Level the table by adjusting the (#5) leg levelers until the table sits evenly on the floor.

7’ AVALON OUTDOOR POOL TABLE





Note: Always cover your pool table when not in use to protect it from harsh weather and debris. To install, center the premium table cover (#6) over the top, adjust it evenly, and pull the elastic bands tight. Secure it in place using the adjustable sliding locks.

1-YEAR LIMITED WARRANTY

This product is warranted to the original purchaser to be free from defects in material or workmanship for a period of 1-Year from the date of the original retail purchase.

This warranty does not cover defects or damage due to improper installation, alteration, accident, or any other event beyond the control of the manufacturer. Defect or damage resulting from misuse, abuse, or negligence will void this warranty. This warranty does not cover scratching or damage that may result from normal usage.

This product is not intended for institutional or commercial use: the manufacturer does not assume any liability for such use. Institutional or commercial use will void this warranty.

This warranty is nontransferable and is expressly limited to the repair or replacement of the defective product. During the warranty period, the manufacturer shall repair or replace defective parts at no cost to the purchaser. Labor charges and related expenses for removal, installation or replacement of the product, or components are not covered under this warranty.

The manufacturer reserves the right to make substitutions to warranty claims if parts are unavailable or obsolete.

The manufacturer shall not be liable for loss of use of the product, or other consequential or incidental costs, expenses or damage incurred by the consumer of any other use.

All warranty claims must be made to Freetime Fun. A purchase receipt with purchase date will be required to process all warranty claims. The model number and part numbers found within the assembly instructions will be required when submitting any parts requests or warranty claims.

BE SURE TO CHECK OUR WEBSITE AT FREETIMEFUN.COM
FOR GREAT NEW GAMES, SAUNAS, PATIO, AND POOL SUPPLIES FOR YOUR HOME AND FAMILY!
WWW.FREETIMEFUN.COM

freetime FUN
BEST IN GAMES, SAUNAS, POOL AND PATIO

1830 E. FABYAN PKWY, BATAVIA, IL 60510
PHONE: 1-888-620-6088
EMAIL: CUSTOMERSERVICE@FREETIMEFUN.COM

TO ORDER REPLACEMENT PARTS
VISIT OUR WEBSITE
WWW.FREETIMEFUN.COM