



BEST IN GAMES, SAUNAS,
POOL AND PATIO

ROCKFORD

7' POOL TABLE WITH TABLE TENNIS TOP
RB4050A



FREETIME FUN
1830 E. FABYAN PKWY.
BATAVIA, IL 60510
WWW.FREETIMEFUN.COM

Check all packaging before discarding.

Be sure all parts identified in the assembly manual
are included.

Don't assemble if parts are missing.

If you are missing parts or have questions please
contact our toll free line at 1-888-620-6088.

Thank you for purchasing this product. If you experience any issues during assembly or use of this product, please don't hesitate to contact Customer Service at 1-888-620-6088 for immediate assistance.

ASSEMBLY TIPS












IMPORTANT! PLEASE READ THESE ASSEMBLY INSTRUCTIONS IN ENTIRETY BEFORE ASSEMBLING YOUR PRODUCT.

Estimated Assembly Time: 1 hour.







1. Find a clean, level surface to begin the assembly of your game table. Assembly will require two adults. You may want to carefully cut the four corners of the box so that the bottom of the box can be used as your work surface.
2. Remove all of the contents from the box and verify that you have all of the parts shown on the Parts List before you begin assembly. **Note:Some parts are pre-installed or pre-assembled.**
3. When installing parts that have more than one screw or bolt, hand tighten all screws or bolts in place before final tightening with screwdriver or wrench.
4. Electric screwdrivers may be helpful during assembly; however, please set a low torque and use extreme caution because screws may be stripped if overtightened, resulting in damaged parts.

► THIS PRODUCT IS INTENDED FOR INDOOR USE ONLY.
DO NOT DRAG THE TABLE WHEN MOVING IT AS THIS MAY CAUSE DAMAGE TO THE LEGS.

ACCESSORIES

<div>12</div> <div></div> <div>Table Tennis Ball XRM17016(3)</div>	<div>13</div> <div></div> <div>Table Tennis Racket XRB12034(2)</div>	<div>14</div> <div></div> <div>Table Tennis Net XRB12035(1)</div>	<div>15</div> <div></div> <div>Table Tennis Net Post XRB12036(2)</div>	<div>16</div> <div></div> <div>Rail Brush XRB12011(1)</div>	<div>17</div> <div></div> <div>Billiard Ball Set XRB12008(1)</div>
<div>18</div> <div></div> <div>Cue Chalk XRB12039(2)</div>	<div>19</div> <div></div> <div>57" Cue Stick XRB12040(2)</div>	<div>20</div> <div></div> <div>Triangle XRB12009(1)</div>	<div>43</div> <div></div> <div>Table Spot XRB12056(2)</div>	<div>44</div> <div></div> <div>9" Table Brush XRB12057(1)</div>	

HARDWARE PACK RB4050A

<div>21</div> <div></div> <div>M8x150mm Bolt(4)</div>	<div>22</div> <div></div> <div>M8x65mm Bolt(12)</div>	<div>23</div> <div></div> <div>M8x40mm Bolt(20)</div>	<div>24</div> <div></div> <div>M8 Washer(36)</div>	<div>25</div> <div></div> <div>3.5*18mm Screw(4)</div>	<div>26</div> <div></div> <div>Allen Wrench (1)</div>
--	--	--	--	---	--

ROCKFORD 7' POOL TABLE WITH TABLE TENNIS TOP

PARTS LIST





TABLE PARTS


1 Table Cabinet XRB12600 (1)	2 Leg Cross Assembly XRB12601 (2)	3 Connection Block XRB12602 (2)	4 Leg Base XRB12603 (2)	5 Cross Beam XRB12604 (1)
6 Table Tennis Top XRB12605 (2)	7 Table Tennis Support Board XRB12506 (1)	8 Leg Leveler Pre-assembly XRB12507 (8)	9 EVA Top Protection Pad XRB12508 (6)	10 Top Alignment Pin Pre-Installed XRB12509 (3)
11 Side Pocket XRB12510 (2)	15 Corner pocket Pre-assembly XRB12511 (4)			

ROCKFORD 7' POOL TABLE WITH TABLE TENNIS TOP


PARTS REFERENCE DIAGRAM



STEP 1




STEP 2



ROCKFORD 7' POOL TABLE WITH TABLE TENNIS TOP ASSEMBLY INSTRUCTIONS


STEP 3



STEP 4


CAUTION: THE TABLE IS HEAVY; IT IS RECOMMENDED THAT FOUR STRONG ADULTS ASSIST IN FLIPPING TABLE OVER TO THE UPRIGHT POSITION AS SHOWN BELOW.

HOLD TABLE CORNER




Firmly grasp the table at each cabinet corner area

CABINET




Carefully rotate the table to the upright position by grasping table top

DO NOT LEAN THE TABLE ON ITS LEGS!



DO NOT HOLD THE LEGS




Position the table in its desired location and level the table to the floor by adjusting the leg levelers

ROCKFORD 7' POOL TABLE WITH TABLE TENNIS TOP ASSEMBLY INSTRUCTIONS


STEP 5

Insert #11 pocket from the underside into the side pocket cutout area, align the pocket with the top rail and secure with two #27 screws.

CAUTION: USE LOW TORQUE DO NOT OVERTIGHTEN AS THIS WILL STRIP THE HOLES.




STEP 6



ROCKFORD 7' POOL TABLE WITH TABLE TENNIS TOP ASSEMBLY INSTRUCTIONS

STEP 7



YOU MAY ALSO WANT

UNIVERSAL POOL TABLE COVER

Will fit 7' and 8' tables. Our lightweight, deluxe cover protects your pool table from fading, spills, dust, and dirt. Oversized for complete coverage. Made from breathable dust proof fabric, the cover has durable double stitched seams and weighted corners to ensure it stays put. 106" L x 64" W. **1-Year Warranty.**



Item#	Description	Price
RB9210	Universal Pool Table Cover	\$19.95

1-YEAR LIMITED WARRANTY

This product is warranted to the original purchaser to be free from defects in material or workmanship for a period of 1-Year from the date of the original retail purchase.

This warranty does not cover defects or damage due to improper installation, alteration, accident, or any other event beyond the control of the manufacturer. Defect or damage resulting from misuse, abuse, or negligence will void this warranty. This warranty does not cover scratching or damage that may result from normal usage.

This product is not intended for institutional or commercial use: the manufacturer does not assume any liability for such use. Institutional or commercial use will void this warranty.

This warranty is nontransferable and is expressly limited to the repair or replacement of the defective product. During the warranty period, the manufacturer shall repair or replace defective parts at no cost to the purchaser. Labor charges and related expenses for removal, installation or replacement of the product, or components are not covered under this warranty.

The manufacturer reserves the right to make substitutions to warranty claims if parts are unavailable or obsolete.

The manufacturer shall not be liable for loss of use of the product, or other consequential or incidental costs, expenses or damage incurred by the consumer of any other use.

All warranty claims must be made to Freetime Fun. A purchase receipt with purchase date will be required to process all warranty claims. The model number and part numbers found within the assembly instructions will be required when submitting any parts requests or warranty claims.

**BE SURE TO CHECK OUR WEBSITE AT FREETIMEFUN.COM
FOR GREAT NEW GAMES, SAUNAS, PATIO, AND POOL SUPPLIES FOR YOUR HOME AND FAMILY!
WWW.FREETIMEFUN.COM**



1830 E. FABYAN PKWY, BATAVIA, IL 60510
PHONE: 1-888-620-6088
EMAIL: CUSTOMERSERVICE@FREETIMEFUN.COM

TO ORDER REPLACEMENT PARTS
VISIT OUR WEBSITE
WWW.FREETIMEFUN.COM